

28.Gas_Sensor

Introduction

Gas Sensor MQ-2 is a sensor for flammable gas and smoke by detecting the concentration of combustible gas in the air. They are used in gas detecting equipment for smoke and flammable gasses in household, industry or automobile.

Hardware Required

- ✓ 1 * Raspberry Pi
- ✓ 1 * Breadboard
- ✓ 1 * Network Cable
- ✓ 1 * PCF8591
- ✓ 1 * Gas Sensor Module
- ✓ 1 * 3-Pin anti-reverse cable
- ✓ 1 * 4-Pin anti-reverse cable
- ✓ Several Jumper wires (M to F)


Principle

MQ-2 Gas Sensor

MQ-2 gas sensor is a kind of surface ion type and N-type semiconductors, which uses tin oxide semiconductor gas sensitive material. When ambient temperature is in 200 ~ 300°C, tin oxide will adsorb oxygen in the air and form oxygen anion adsorption to decrease electron density in semiconductor so as to increase its resistance. When in contact with the smoke, if grain boundary barrier is modulated by the smoke and changed, it could cause surface conductivity change. So you can gain the information of the smoke existence, The higher the smoke concentration is, the more conductive the material becomes, thus the lower the output resistance is.

In this experiment, if harmful gases reach a certain concentration, the buzzer will beep to warn.

28.Gas_Sensor



Schematic Diagram


Raspberry Pi	PCF8591 Module	Gas Sensor Module
SDA	SDA	*
SCL	SCL	*
3V3	VCC	*
GND	GND	GND
5V	*	VCC
GPIO00	*	DO
*	AIN0	AO

Raspberry Pi	Active Buzzer Module
GPIO1	SIG
5V	VCC
GND	GND

Experimental Procedures

Step 1: Build the circuit

28.Gas_Sensor



For C language users:

Step 2: Change directory

```
cd /home/pi/REXQualis_Raspberry_Pi_Complete_Starter_Kit/C/28.Gas_Sensor
```

Step 3: Compile

```
gcc 28.Gas_Sensor.c -o Gas_Sensor.out -lwiringPi
```

Step 4: Run

```
sudo ./Gas_Sensor.out
```

Place a lighter close to the MQ-2 gas sensor, and press the switch to release gasses. A value between 0 and 255 will be displayed on the screen. If harmful gases reach a certain concentration, the buzzer will beep, and “Danger Gas!” will be printed on the

28.Gas_Sensor

screen.

You can also turn the shaft of the potentiometer on the module to raise or reduce the concentration threshold.

The MQ-2 gas sensor needs to be heated up for a while. Wait until the value printed on screen stays steady and the sensor gets warm, which means it can work normally and sensitively at that time.

Note: It is normal that the gas sensor generates heat. Actually, the higher the temperature is, the sensor is more sensitive.

Code

```
#include <stdio.h>
#include <wiringPi.h>
#include <pcf8591.h>
#include <math.h>

#define PCF 120
#define DOpin 0
#define Buzz 1

void Print(int x)
{
    switch(x)
    {
        case 1:
            printf("\n*****\n");
            printf(" * Saft~ *\n");
            printf("*****\n\n");
            break;
        case 0:
            printf("\n*****\n");
    }
}
```

28.Gas_Sensor

```
    printf(  "* Danger Gas! *\n"  );
    printf(  "*****\n\n");
break;
default:
    printf("\n*****\n" );
    printf(  "* Print value error. *\n"  );
    printf(  "*****\n\n");
break;
}
}

int main()
{
    int analogVal;
    int tmp, status, count;

    if(wiringPiSetup() == -1){
        printf("setup wiringPi failed !");
        return 1;
    }

    // Setup pcf8591 on base pin 120, and address 0x48
    pcf8591Setup(PCF, 0x48);

    pinMode (DOpin, INPUT);
    pinMode (Buzz, OUTPUT);
    digitalWrite(Buzz, HIGH);

    status = 0;
    count = 0;
```

28.Gas_Sensor

```
while(1) // loop forever
{
    analogVal = analogRead(PCF + 0);
    printf("%d\n", analogVal);

    tmp = digitalRead(DOpin);

    if (tmp != status)
    {
        Print(tmp);
        status = tmp;
    }

    if (status == 0)
    {
        count++;
        if (count % 2 == 0)
            {digitalWrite(Buzz, HIGH);}
        else
            {digitalWrite(Buzz, LOW);}
    }
    else
    {
        count = 0;
        digitalWrite(Buzz, HIGH);
    }
    delay (200);
}

return 0;
```

28.Gas_Sensor

{}

For Python users:

Step 2: Change directory

```
cd /home/pi/REXQualis_Raspberry_Pi_Complete_Starter_Kit/Python
```

Step 3: Run

```
sudo python3 28.Gas_Sensor.py
```

Code

The code here is for Python3, if you need for Python2, please open the code with the suffix py2 in the attachment.

```
#!/usr/bin/env python3

import PCF8591 as ADC
import RPi.GPIO as GPIO
import time
import math

DO = 17
Buzz = 18
GPIO.setmode(GPIO.BCM)

def setup():
    ADC.setup(0x48)
    GPIO.setup(DO, GPIO.IN)
    GPIO.setup(Buzz, GPIO.OUT)
    GPIO.output(Buzz, 1)

def Print(x):
    if x == 1:
        print()
```

28.Gas_Sensor

```
print('*****')
print('* Safe~ *')
print('*****')
print()

if x == 0:

    print()
    print('*****')
    print('* Danger Gas! *')
    print('*****')
    print()

def loop():

    status = 1
    count = 0

    while True:

        print(ADC.read(0))

        tmp = GPIO.input(DO)
        if tmp != status:
            Print(tmp)
            status = tmp

        if status == 0:
            count += 1
            if count % 2 == 0:
                GPIO.output(Buzz, 1)
            else:
                GPIO.output(Buzz, 0)
        else:
            GPIO.output(Buzz, 1)
```

28.Gas_Sensor

```
count = 0

time.sleep(0.2)

def destroy():
    GPIO.output(Buzz, 1)
    GPIO.cleanup()

if __name__ == '__main__':
    try:
        setup()
        loop()
    except KeyboardInterrupt:
        destroy()
```

Phenomenon Picture

